


RG-S2928G-S




A solid red horizontal bar located to the left of the "Contents" text.

Contents




RG-S2928G-S




USB2.0
CLI Web
SNMP

A solid red rectangular bar located to the left of the "Contents" text.

Contents





24 10/100/1000M

2

Console


9600bps


USB

FAT

U

U








1.6 SFP
RG-S2928G-S 27F,28F


5G

SFP





web



ACL IP+MAC)

SNMP Telnet

