




:C







UPS

0 ~40

5%~90%



RUIHE

www.ruihe.com.cn



RUIHE

www.ruihe.com.cn



100-240V~/47-63Hz

-40.0V~72V


RSR-08M

1+1


" "

f


‰



RE




MIC





RUIHE

www.ruihe.com.cn



show chassis hardware

show version



RUIHE

www.ruihe.com.cn



```
flash
messages
notice
notice any
root@ruijie# set system syslog file messages any notice
root@ruijie#
```

www.ruijie.com.cn

www.ruijie.com.cn/service.aspx

support.ruijie.com.cn

webchat.ruijie.com.cn

4008-111-000