


RG-ES08, ES08G

Series Switch Quick Installation Guide

!

A6c

16F503PF740kP




1

1		1	
2	1.2m	1	
3		1	

- (1)

M3
- (2)



a b



! A66

16FA03PFW40

+K7 >



1-8

www.ruijie.com.cn

Copyright © ruijie networks Co., Ltd.

618

<http://bbs.ruijiery.com>

+86-400-100-0078(China)

<https://www.ruijiery.com>

<https://www.ruijie.com.cn>

Ruijie Ethernet Switches Installation Quick Start

This quick start applies to RG-ES08 and RG-ES08G, the execution standards include GB 4943.1.

Operation of this equipment in a residential environment could cause radio interference.

1: Nameplate on the bottom of the device.

Package Contents

Number	Item	Quantity
1	Switch	1
2	Power adapter (power cord length 1.2 m)	1
3	Quick Installation Guide	1

Install the Device

Wall Mounting

- (1) Step1: Drill two holes in the wall based on the distance between the two slots on the bottom panel of the switch. Pu[O]-4(gBDC q418.15 337.25 120.38 17)13(e)-3(e)-3(n)-3(t)-3(h)9(e)-3(t)-3(w)15(o)-3(s)-8(l)-4(o)Tm0.1339 Tm[S

Desktop Mounting

Place the switch upside down on a stable and flat desktop.

Connect the Device

Refer to scenario **A** or **B** for networking guidance based on your actual situation.



Open the top cover of the switch by pulling the latch on the top cover.

For more information about the product and installation procedures, log in to www.ruijie.com.cn

Copyright © ruijie networks Co., Ltd.

RUIJIE NETWORKS CO., LTD.

Ruijie Science and Technology Park, Juyuanzhou, No. 618, Jinshan Road, Fuzhou

Technical Support: <http://bbs.ruijiery.com> Technical Support Hotline: +86-400-100-0078(China)

Website: <http://www.ruijiery.com> <http://www.ruijie.com.cn>